

GSM Plug-in with Data Plan

For Australia and New Zealand

SE1000-GSM02 SE-SIM-R12-XX-S1 / SE-SIM-R12-XX-S2*



Mobile Internet Connectivity

- Connects SolarEdge inverters wirelessly to the Internet
- No need for Internet infrastructure at site
- Installed within the inverter enclosure for outdoor resilience
- Enables remote analysis and troubleshooting
- Supports low bandwidth configuration for reduced data usage and cost
- Can be used with SolarEdge data plan or third-party SIM card

Note - For a detailed coverage map refer to the following link and select the 3G GSM option: http://www.aeris.com/technology/aerconnect/coverage-map/#modal

^{*} XX = AU for data plans in Australia, XX = NZ for data plans in New Zealand



GSM Plug-in & Data Plans

For Australia and New Zealand

SE1000-GSM02 SE-SIM-R12-XX-S1 / SE-SIM-R12-XX-S2

COMPATIBLE INVERTERS	SEXXXXX-XXXXXXXXX		UNIT
DATA PLAN	High Bandwidth Mode	Low Bandwidth Mode	
Number of Inverters Monitored with a Single Mobile GSM Plug-in	Up to 32	1	
Monitoring	Data sampled every 5 minutes and sent to SolarEdge server continuously*	Data sampled every 15 minutes and sent to SolarEdge server every 4 hours	
Monthly Data - per Inverter	7.8	2.6	MB
Monthly Data - per Optimiser	0.15	0.05	MB
Monthly Data - per Revenue Grade Meter	0.3	0.1	MB
Monthly Data - per Export or Consumption Meter	3	0.55	MB
Monthly Data - per Battery	3	0.7	MB
Monthly data - per Commercial Gateway or Firefighter Gateway	3	Not supported	МВ
Compatible with 3rd party SIM card		<u>/</u>	
Compatible with SolarEdge data plan	X	√	
RF PERFORMANCE			
Operating Frequency MinMax. 900	Modem transmit: 880-915 / Modem receive: 925-960		MHz
Operating Frequency MinMax. 1800	Modem transmit: 1710-1785 / Modem receive: 1805-1880		MHz
Operating Frequency MinMax. 2100	Modem transmit: 1920 -1980 / Modem receive: 2110 -2170		MHz
Antenna	Included, 2dBi outdoor; Dual band antenna: 824-960MHz / 1710-2170MHz		
Maximum output power: 0.9GHz / 1.8GHz / 2.1GHz band	33 / 30 / 24		dBm
Receiver Input Sensitivity (Downlink RF level @ BER Class II < 2.4 %)	Typical -109		dBm
STANDARD COMPLIANCE			
Emissions and Radio	EN 301-489-1, EN 301-489-7, EN 301-511		
INSTALLATION SPECIFICATIONS			
Dimensions (L x W)	90.5 x 34.5 / 3.55 x 1.35		mm/in
Operating Temperature	-40 to +85 / -40 to +185		°C/°F
Mounting	Built into the inverter or installed as an upgrade kit **		
SIM CARD HOLDER			
Туре	Micro-SIM***		

 $[\]ensuremath{^{*}}$ Up to 90MB/month of overhead per site may be observed, depending on SIM card provider

^{***} Non-SolarEdge SIM cards must be 3G GSM compatible. If the SIM is intended for use in Low Bandwidth mode it must have SMS capabilities

	SolarEdge Data Plans for Low Bandwidth Mode		
	SE-SIM-R12-AU-S1 / SE-SIM-R12-NZ-S1	SE-SIM-R12-AU-S2 / SE-SIM-R12-NZ-S2	
	Residential systems:	Residential StorEdge systems:	
Supported Systems	one inverter, up to 60 power optimisers,	one inverter, up to 60 power optimisers,	
	and 2 meters	up to two batteries, and 2 meters	
Monitoring	Data sampled every 15 minutes and sent to SolarEdge server every 4 hours (Low Bandwidth Mode)		
Number of Monitored Inverters with a Single Mobile GSM Plug-in	1		
Plan Duration	12 year prepaid plan		

^{**} The GSM upgrade kit is available under the following part numbers: for single phase inverters SE-1PH-GSM-K1, for three phase inverters SE-3PH-GSM-K2



SolarEdge Mobile GSM Offering

	GSM Upgrade Kit	Rate Plan
Description	Replacement inverter communication board with pre-installed mobile GSM modem	SIM card with data plan
Supported Systems	Single and three phase inverters with CPU version 3.xxxx and above	Residential and StorEdge systems
Part Number	SE-1PH-GSM-K1 (for single phase inverters) /	SE-SIM-R12-XX-S1 (residential) /
	SE-3PH-GSM-K2 (for three phase inverters)	SE-SIM-R12-XX-S2 (StorEdge)*

 $^{^{*}}$ XX = AU for data plans in Australia, XX = NZ for data plans in New Zealand



